8.5”

5.5”

Troubleshooting

If the unit does not function properly, check the following points before contacting the service center.

Problem	Cause & Remedies
NO Power	Check the AC outlet , AC Adapter and turn the power switch ON
NO Picture	Connect the Yellow-Plug to the Monitor or TV correctly
Picture flickering	Remove strong spotlight in the field of view
Dim picture, too bright/dark	Please adjust brightness level of your Monitor or TV properly
Rolling or jumping Picture	Please adjust V-Hold level of your Monitor or TV properly

How to Obtain Factory Service

1. Original Purchaser must fill out a warranty card and mail it to Clover Electronics with model number, serial number and date of purchase.
2. Please pack the products carefully and securely by using the original packing materials, and send it prepaid and insured to: 13073 E. 166th St. Cerritos, CA 90703.
   Please include a note stating how the unit is defective.
3. If the unit is returned within the warranty period, please include a proof of purchase and check for $15.00 to cover the cost of return postage and handling.
   If the unit is out of warranty, please include a check for $15.00 to cover the cost of return postage and handling. You will receive an estimate of the repair cost for your approval before repair work will be started.
4. Clover will repair or replace and return the products to the owner under this limited warranty.

Limited 1 year Warranty

This warranty gives the original purchaser specific legal rights and you may also have rights, which may vary from state to state.

If our products do not function because of any defect in material or workmanship, we will repair it for free for 1 year on parts and labor from the date of original purchase.

This warranty does not cover modification, abuse, incidental or consequential damages unless the state of owner's residence specially prohibits limitation on incidental or consequential damages.

Wisecomm
www.wisecomm.com

Copyright © 2009 Wisecomm Inc. All Rights Reserved

For Technical Support Call 877-799-8500

USER'S INSTRUCTIONS

High Resolution Color CCD

Security Camera

Indoor / Outdoor Weather Resistant

MODEL # OC175



Wisecomm
www.wisecomm.com

Copyright © 2009 Wisecomm Inc. All Rights Reserved

www.wisecomm.com

8.5”

5.5”

Connection



1. Lens.
2. 12 Night Vision IR LEDs
3. CDS Sensor(Automatically Turns IR LEDs On/Off as Required)

FEATURES

- Easy to Install
- High Quality Image
- Ideal for Home or Business Use
- Can See in Total Darkness up to 30’
- CDS Sensor Turns IR LEDs On/Off as Required
- Weather Resistant Metal Housing
- Use with Any DVR or VCR

SPECIFICATIONS

Image Pickup Device	Color CCD Sensor
TV System	NTSC
No. of Pixels	512 (H) x 492 (V)
Resolution	380 TV Lines
Minimum Illumination	0.5 Lux/F1.2
Video Output	1V p-p 75 Ohms
Power Supply	DC 12V
Lens	3.6mm F 2.0

Package Includes

1 - Night Watchman Camera
1 - Warranty Registration Card
1 - User's Manual

Conexión



1. Lente.
2. 12 Focos Infrarojos LED Para Ver in el Noche.
3. Sensor CDS Automaticamente Prende y Apaga Los Focos Infrarojos Cuando Necesite.

ATRIBUTOS

- Facil - de - Install
- Cámera(CCD) Profesiónal de Alta Resolutión
- Simplemente Connecte a Su Televisor o Monitor
- Ideal Para Casa or Negocio
- Puede Mirar Hasta 30’ Pies en Completa Oscuridad
- Sensor Apaga LED’s Durante el Dia
- Asemblaje Resistante al Clima

ESPECIFICACIONES

Sensor de Imagen	Sensor de Imagen a Color CCD
Sistema de Video	NTSC
Resolución	380 Lineas
Control de Apertura	Auto 1/60 ~ 1/100,000 Segundos
Applicación de Cámera	Cámera Diseñada Para Uso Interior y Exterior
Illuminación Minima	0.5 Lux F1.2
Requirimientos de Poder	12V (Via el Adaptador de Poder)
Lente	3.6mm F 2.0

Package Includes

1- Cámera a Color Para el Exterior con Montage
1- Manual de Instrucciones
1- Targeta de Garantia